






DU70/DU71/DU72 Series

Digital Projector Quick Start Guide

- Guide de démarrage rapide du projecteur numérique
- Digitaler Projektor Kurzanleitung
- Guida rapida del proiettore digitale
- Guía de inicio rápido del proyector digital
- Guia de iniciação rápida ao Projetor Digital
- Digital projektor snabbstartsguide
- Краткое руководство по работе с цифровым проектором
- Snelgids voor Digitale projector
- Skrócona instrukcja obsługi projektora cyfrowego
- Dijital Projektör Hızlı Başlangıç Kılavuzu
- Průvodce rychlým používáním digitálního projektoru
- คู่มือเริ่มต้นใช้งานดีจิทัลโปรเจคเตอร์อย่างย่อ
- デジタルプロジェクタ クイックスタート ガイド
- 디지털 프로젝터 빠른 시작 안내서
- 數位投影機快速使用指南
- 数字投影机快速使用指南
- دليل البدء السريع لجهاز عرض رقمي






1



2




3



4



5



OR

